



CUT-OFF MECHINE spare parts list

No.	Part Name	QTY	No.	Part Name	QTY
1	Screw ST3.9*14	10	41	6202 Bearing	1
2	Rear cover	1	42	Screw ST4.9*75	2
3	Housing	1	43	M5 Lock nut	5
4	Wind baffle	1	44	M5 Screw	2
5	6000 Bearing sleeve	1	45	3502 Movable cover	1
6	6000 Bearing	2	46	Anti-dust cover	1
7	220V Armature	1	47	M6*16 Pan head screw	1
8	220V Field coil	1	48	M6*16 Hexagon screw	6
9	3501 Lock pin	1	49	M6 Lock nut	1
10	3501 Lock pin spring	1	50	M10*20 Six angle screw with shim	1
11	3502 Head case	1	51	M10*20 Six angle screw	1
12	Gear	1	52	3502 Iron back plate	1
13	3502 Front housing	1	53	3502 Pedestal	1
14	20 Ciclip	1	54	3502 Spanner	1
15	6204 Bearing	1	55	8 Washer	1
16	3502 Output shaft	1	56	M8 Nut	1
17	6 Spring washer	4	57	11 Cotter pin	1
18	6 Flat washer	4	58	8 Spring washer	2
19	4 Round buckle	4	59	8 Flat washer	2
20	3502 Pressplate	2	60	M8*20 Pan head screw	2
21	3501 Cutting piece	1	61	Fixed support	1
22	5*16 Woodruff key	1	62	Support stamping	1
23	3502 Gland	1	63	4 Cotter pin	1
24	M10*25 Screw	1	64	8 Shaft clamp	1
25	3502 Rear cover	1	65	8 Washer	1
26	Right handle	1	66	Handle	1
27	1040 Sheath	1	67	Handle pin	1
28	M10*90 Screw	1	68	3502 Trigger	1
29	M10*17 Nut	1	69	Cabel plug	1
30	Spacer pin	1	70	Moving cleat	1
31	Connection pin	1	71	Cleat connection pin	1
32	5 Spring washer	7	72	Plastic cleat	1
33	5 Flat washer	7	73	Pedestal assembly	1
34	M5*40 Screw	4	74	Lead screw	1
35	15 Anti-dust washer	1	75	Plastic sleeve	2
36	M5*25 Screw	3	76	3502 Torsional spring	1
37	2.5*35 O Ring	1	77	3502 Brush holder	2
38	92352 Cable clamp	1	78	3502 Carbon brush	2
39	Left handle	1	79	3502 Brush holder cover	2
40	3502 Switch	1			